

PRESSURE/TORQUE CONVERSION CHART

10MD

Pressure in PSI	Pressure in BAR	FT. LBS.	Nm
1000	69	1050	1424
1200	83	1282	1738
1400	97	1490	2020
1600	110	1710	2318
1800	124	1935	2624
2000	138	2140	2901
2200	152	2380	3227
2400	165	2605	3532
2600	179	2810	3810
2800	193	3055	4142
3000	207	3265	4427
3200	221	3510	4759
3400	234	3725	5050
3600	248	3930	5328
3800	262	4145	5620
4000	276	4380	5938
4200	290	4585	6216
4400	303	4810	6521
4600	317	5035	6827
4800	331	5285	7165
5000	345	5510	7471
5200	359	5735	7776
5400	372	5950	8067
5600	386	6190	8393
5800	400	6410	8691
6000	414	6630	8989
6200	427	6845	9281
6400	441	7060	9572
6600	455	7300	9897
6800	469	7520	10196
7000	483	7755	10514
7200	496	7980	10819
7400	510	8200	11118
7600	524	8425	11423
7800	538	8645	11721
8000	552	8880	12040
8200	565	9090	12324
8400	579	9315	12629
8600	593	9545	12941
8800	607	9765	13240
9000	621	10000	13558
9200	634	10230	13870
9400	648	10460	14182
9600	662	10670	14467
9800	676	10900	14778
10000	689	11206	15193

MAXDRIVE™ SERIES
SQUARE DRIVE TORQUE WRENCHES